

MODEL: LS-815 "STINGER"

5 WATTLED ALUMINIUM ALLOY RECHARGEABLE FLASHLIGHT



PHYSICAL AND MECHANICAL DATA

SIZE IN MILLIMETRES	WEIGHT	PACKAGING	LIGHT SOURCE
Head Width : 32 mm Body Width : 24 mm Length : 140 mm	85 Gram (without battery)	Box	5 W, Q5 Cree LED 600 Lumen

POWER SOURCE

Rechargeable 18650 Lithium-ion 3.7V 2,600 mAh battery (Minimum charge cycles: 700)

CHARGE ACCESSORIES INCLUDED

1x 18650 Lithium-ion 3,7V 2,600 mAh



External Battery Charger with Cable



OPTIONAL ACCESSORIES

DC 12V USB Car Adaptor USB



Pouch



USB Wall Adaptor



SPECIFICATIONS: (When Battery is fully charged)

- Constant Burn Time at 100% : 2,5 hrs
- Constant Burn Time at 50% : 5 hrs
- Constant Burn Time at 25% : 10 hrs
- Constant Burn Time – Strobing : 2,5 hrs
- Constant Burn Time – SOS : 2,5 hrs

FEATURES

- 5 Mode Settings: 100% - 50% - 25% - Strobing - SOS
- Super Strong Aluminium Alloy Body
- Military Spec Hard Anodising (Black)
- Cree LED – 100,000 hr Lifetime
- Lasts much longer than conventional incandescent globes
- New built in energy management system, results in longer battery life
- Impact resistant: Drop – 1,5m
- Weather Resistant
- Beam Distance: 300m (Flood to focus function)

APPLICATION

- A flashlight to use in all conditions and circumstances, robust enough to deal with rough handling and falling.
- The disorienting strobe effect allows the user to deal with violent individuals in dangerous low light and dark conditions.

OPERATING INSTRUCTIONS

- Press Switch Button Once: 100% Brightness
- Press Switch Button Again: 50% Brightness
- Press Switch Button Again: 25% Brightness
- Press Switch Button Again: Disorientating Strobe (100% Brightness)
- Press Switch Button Again: SOS
- Press Switch Button Again: Off

CHARGING INSTRUCTIONS (WHEN USING CHARGE CONTROL, OR STANDARD CHARGE CABLE)

Very Important:

- *Input voltage into flashlight must never exceed 4.2V – regardless of battery quantity (higher voltage will damage batteries).*

- *Charging ampere rating: between 1 to 3 amp (depending on battery quantity).*

- *Always switch flashlight off during charging.*

- Remove battery from flashlight and insert into external battery charger, observing the correct polarity.
- Insert male plug of USB charge cable into female socket in external battery charger.
- Insert USB connector (plug) of charge cable into either AC Adaptor, DC Adaptor or computer USB port.
- The LED power indicator in battery charger will show RED continuously to indicate that power is on
- Charge time: 4 hours
- Over time, unused batteries will discharge and must be recharged before use.
- Use batteries only for intended purpose.
- Disconnect chargers from power sources when not in use.
- Do not leave flashlight unattended while ON

CAUTION: Total discharge of battery (totally flat) is dangerous and will shorten battery life

